


# CUCINA



### ZA017.5


Monocomando cucina canna nera  
Single lever sink mixer  
Küchen-Einhebelmischbatterie

#### ZA017.5

CR



Ø 35 mm



### CO119.5/10


Monocomando cucina con canna snodata grigia  
Single lever sink mixer  
Küchen-Einhebelmischbatterie

#### CO119.5/10

CR



Ø 35 mm



### CO119.5/11


Monocomando cucina con canna snodata grigia  
**con doccetta a 2 getti**  
Single lever sink mixer  
Küchen-Einhebelmischbatterie

#### CO119.5/11

CR



Ø 35 mm




## SA 71

Mix cucina canna ultrapiatta cromato  
*Chrome sink mixer, ultra-flat spout*  
*Küchen-Einhebelmischbatterie*

### SA 71

CR




## SA 72

Mix cucina con canna a taglio cromato  
*Chrome sink mixer*  
*Küchen-Einhebelmischbatterie*

### SA 72

CR



Particolare aeratore a scomparsa  
*Retractable aerator detail*